- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

		Function									
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor			
Test by System	ENGINE	√	√	√	√	√	√	√			
Test by System	TRANSMISSION	√	√	√	√	√	$\checkmark$	$\checkmark$			
Test by System	ABS	√	√	√	√	√	$\checkmark$	√			
Test by System	AIR BAG	√	√	√	√	_	√	$\checkmark$			
Test by System	BCM	√	√	√	√	√	√	√			
Test by System	METER/M&A	√	√	√	√	_	_	√			
Test by System	HVAC	√	√	√	√	√	√	$\checkmark$			
Test by System	ICC/ADAS	√	√	√	√	√	$\checkmark$	√			
Test by System	MULTI AV	√	√	√	√	√	√	$\checkmark$			
Test by System	EHS/PKB	√	√	√	√	_	_	_			
Test by System	MOTOR CONTROL	√	√	√	√	-	-	_			
Test by System	EPS/DAST 3	√	√	√	√	_	-	√			
Test by System	IPDM E/R	√	√	√	√	√	_	_			
Test by System	AIR PRESSURE MONITOR	√	√	√	√	√	√	√			
Test by System	BAC	√	√	√	√	_	_	_			
Test by System	SUB METER	_	√	√	√	_	_	_			
Test by System	CONVERTIBLE ROOF	√	√	√	√	√	√	√			
Test by System	HEAD LAMP LEVELIZER	√	√	√	√	√	√	√			
Test by System	e-4WD	√	√	√	√	√	_	_			
Test by System	LASER/RADAR	√	√	√	√	_	$\checkmark$	√			
Test by System	INTELLIGENT KEY	√	√	√	√	√	$\checkmark$	$\checkmark$			
Test by System	DIU	_	√	√	√	_	_	_			
Test by System	AUTO SLIDE DOOR	√	√	√	√	√	√	_			
Test by System	PRECRASH SEATBELT	√	√	√	√	_	√	_			
Test by System	AUTO DRIVE POS.	√	√	√	√	√	√	√			
Test by System	ALL MODE AWD/4WD	√	√	√	√	√	√	_			
Test by System	DIFF LOCK	√	√	√	√	-	-	_			
Test by System	4WAS (MAIN)/RAS/HICAS	√	√	√	√	√	_	_			
Test by System	SONAR	√	<i>√</i>	√	√	√	√	_			

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

	Vehicle menu		Function							
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor		
Test by System	LANE CAMERA	√	√	√	√	√	√	√		
Test by System	ADAPTIVE LIGHT	√	√	√	√	√	√	$\checkmark$		
Test by System	AUTO SLIDE DOOR RIGHT	√	√	√	√	√	_	_		
Test by System	CAN GATEWAY	√	√	√	√	_	-	_		
est by System	SHIFT	√	√	√	√	_	_	_		
est by System	EV/HEV	√	√	√	√	√	-	_		
est by System	POP UP HOOD	√	√	√	√	_	_	_		
est by System	AUTO BACK DOOR	√	√	√	√	_	√	_		
est by System	Diag Data Recorder	_	√	√	_	-	-	_		
est by System	4WAS (FRONT)	√	√	√	√	√	√	_		
est by System	E-SUS	√	√	√	√	√	√	_		
est by System	ACCELE PEDAL ACT	√	√	√	√	√	-	_		
est by System	HV BATTERY	√	√	√	√	_	-	_		
est by System	TOTAL ILLUM C/U	√	√	√	√	√	√	_		
est by System	OCCUPANT DETECTION	_	_	_	√	_	-	_		
est by System	SmFOB	√	√	√	√	_	-	_		
est by System	BRAKE	√	√	√	√	_	-	_		
est by System	SIDE RADAR LEFT	√	√	√	√	√	√	_		
est by System	ANC	√	√	√	√	_	-	_		
est by System	MULTI DISPLAY	_	√	√	√	√	-	_		
est by System	SIDE RADAR RIGHT	√	√	√	√	√	√	_		
est by System	ADCM	√	√	√	√	_	_	_		
est by System	CHARGER/PD MODULE	√	√	√	√	_	-	_		
est by System	PTC HEATER	√	√	√	√	√	√	_		
est by System	TELEMATICS	√	√	√	√	-	√	_		
est by System	HAS	√	√	√	√	-	-	_		
est by System	EMCM	√	√	√ √	√	_	-	_		
est by System	SVT	√	√	√	√	_	√	_		
est by System	BSW/BUZZER	√	√	√ √	√	_	_	√		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function 3.compared with the last version, the new added function is marked in red color.

Vehicle menu			Function									
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor				
Test by System	AVM	√	√	√	√	_	√	_				
Test by System	CHASSIS CONTROL	√	√	√	√	_	_	_				
Test by System	DAST 1	√	√	√	√	_	_	_				
Test by System	DAST 2	√	√	$\checkmark$	$\checkmark$	_	_	_				
Test by System	HIGH BEAM ASSIST	√	√	√	√	_	_	_				
Test by System	CIU	√	√	√	√	√	√	_				
Test by System	MM CONN	√	√	√	√	_	$\checkmark$	_				
Test by System	ICC/ADAS 2	√	√	√	√	_	_	$\checkmark$				
Test by System	Lane camera 2	√	√	√	√	_	_	-				
Test by System	CAN GATEWAY3	√	√	√	√	_	_	_				
Test by System	(TBD) GEN-INV	√	√	√	√	_	-	-				
Test by System	CAN GATEWAY2	√	√	√	√	-	-	_				
Test by System	Vehicle data transmitter	√	√	√	√	_	-	-				
Test by System	Cluster	√	√	√	√	√	√	_				
Test by System	NATS IMMU	√	√	√	-	-	-	_				
Test by System	SMART ENTRANCE	_	√	√	√	√	√	_				
Test by System	AIR LEVELIZER	√	√	√	√	√	√	-				
Test by System	REARVIEW CAMERA	√	_	_	√	_	√	_				
Test by System	S/BLIND CAMERA	√	_	_	√	_	√	_				
Test by System	ACTIVE ENG MOUNT	√	√	√	√	√	-	-				
Test by System	ACTIVE SUS	_	√	√	√	_	_	_				
Test by System	ASCD	_	√	√	√	_	_	_				
Test by System	HANDS FREE MODULE	√	√	√	√			_				
Test by System	DISTANCE CONTROL	_	√	√	√	√	-	-				
Test by System	MOTOR ASSIST	√	√	√	√	_	-	_				
Test by System	IVMS	_	√	√	√	√	-	-				
Test by System	TCS	_	√	√	√	√	-	-				
Test by System	СНА	√	√	√	√	√	√	-				
Test by System	VSP	√	√	√	√	_	_	_				

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

	Vehicle menu	Function								
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor		
Γest by System	FSCM	√	√	√	√	_	_	_		
Test by System	PMAS	√	√	√	√	_	-	_		
Test by System	RADIO	√	√	√	√	√	√	-		
Test by System	Left front door control unit	√	√	√	√	_	-	_		
Test by System	Right front door control unit	√	√	√	√	_	_	_		
Test by System	Siren control unit	√	√	√	√	_	_	_		
Test by System	Alarm siren	√	√	√	√	_	_	_		
Test by System	Passenger seat control unit	√	√	√	√	_	_	_		
est by System	Intelligent battery sensor	√	√	√	√	_	_	_		
est by System	Upper control panel cont unit	√	√	√	√	_	-	_		
est by System	EC mirror compass	√	√	√	√	_	-	-		
est by System	Universal garage door opener	√	√	√	√	-	-	-		
est by System	Light&rain sensor	√	√	√	√	_	_	-		
est by System	Overhead control panel unit	√	√	√	√	_	_	_		
est by System	Electronic ign switch cont unit	√	√	√	√	_	-	-		
est by System	Trailer recognition control unit	√	√	√	√	_	-	_		
est by System	Occupant classification unit	√	√	√	√	-	-	_		
est by System	ICC sensor	√	√	√	√	-	-	-		
est by System	Parking assist	√	√	√	√	-	_	_		
est by System	Steering column cont module	√	√	√	√	_	-	_		
est by System	Steering wheeling switch pad	√	√	√	√	-	-	-		
est by System	Radar sensor	√	√	√	√	_	_	-		
est by System	LED H/L control module RH	√	√	√	√	-	_	-		
est by System	LED H/L control module LH	√	√	√	√	-	_			
est by System	Side radar RH	√	√	√	√	-	_	√		
Test by System	Side radar LH	√	√	√	√	_	_	_		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function 3.compared with the last version, the new added function is marked in red color.

Vehicle menu		Function								
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor		
Test by System	Front camera unit	√	√	√	√	_	_	_		
Test by System	PT cont module	√	√	√	√	_	_	_		
Test by System	H/L control module RH	√	√	√	√	-	-	_		
Test by System	H/L control module LH	√	√	√	√	-	-	-		
Test by System	(TBD)Audio Amplier Unit	<b>√</b>	√	√	<b>√</b>	-	-	-		