

Model	System	System model	Function						
			Read ECU Info	Read DTCs	History DTCs	Erase DTCs	Live Data	Actuation Test	Remark(other functions)
Kato Machinery	Hino engine control module	J08EUJ Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J08ETV Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J05DTF Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	E13CUY Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	P11CUR Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J08EUR Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	E13CVA Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	E13CVB Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	P11CUV Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J08EUP Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J08EUS Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J08EUL Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J08EUT Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J08EUU Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	J05ETF Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	E13CVC Engine	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	Training Board	√	√	√	√	√	√	Read and write injector data, boost testing and speed limit setting function
Kato Machinery	Hino engine control module	A09C	√	√	√	√	√	√	Read and write injector data, boost testing function
Kato Machinery	Hino engine control module	A09CTJ	√	√	√	√	√	√	Read and write injector data, boost testing function
Kato Machinery	Hino engine control module	A09CTK	√	√	√	√	√	√	Read and write injector data, boost testing function
Kato Machinery	Hino engine control module	U2 Engine	√	√	√	√	-	-	-
Kato Machinery	FUSO engine control module	E906	√	√	-	√	√	-	-
Kato Machinery	FUSO engine control module	E90F	√	√	-	√	√	√	-
Kato Machinery	FUSO engine control module	E916	√	√	-	√	√	√	-
Kato Machinery	FUSO engine control module	E918	√	√	-	√	√	√	-
Kato Machinery	FUSO engine control module	E91E	√	√	-	√	√	√	-
Kato Machinery	FUSO engine control module	EA01	√	√	√	√	√	√	-
Kato Machinery	FUSO engine control module	EA02	√	√	√	√	√	√	-
Kato Machinery	FUSO engine control module	EA03	√	√	√	√	√	√	-
Kato Machinery	FUSO engine control module	EA07	√	√	√	√	√	√	-