

## Diagnostic List Bendix\_v5.19

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Model	System Types	ECU Info	Read Codes	Erase Codes	Read Data	Active Test	Remark (other functions)
Bendix	EC-17	✓	✓	✓	-	✓	Controller Configuration, Rest ABS Controller
Bendix	EC-30	✓	✓	✓	✓	✓	Rest ABS Controller, Controller Configuration
Bendix	EC-60	✓	✓	✓	✓	✓	Rest ABS Controller, Dyno Mode, Calibrate ESP Sensors
Bendix	EC-80	✓	✓	✓	✓	✓	Reset ABS Controller, Calibrate ESP Sensors
Bendix	TABS6	✓	✓	✓	✓	✓	Reset ABS Controller
Bendix	A18	✓	✓	✓	✓	✓	Reset ABS Controller
Bendix	ABS U1x	✓	✓	✓	✓	✓	Tire Size
Bendix	ABS2x	✓	✓	✓	✓	✓	Reset ABS Controller, Controller Configuration
Bendix	AutoVue3G	✓	✓	✓	-	✓	Controller Configuration
Bendix	EC-30T	✓	✓	✓	-	✓	-
Bendix	FLC20	✓	✓	✓	✓	-	SPTAC Calibration
Bendix	MC-30	✓	✓	✓	✓	✓	Rest ABS Controller
Bendix	SDP	✓	✓	✓	✓	✓	-
Bendix	TABS6 MV	✓	✓	✓	✓	-	-
Bendix	TABS6 MV MC	✓	✓	✓	✓	-	-
Bendix	TABS6 Advanced 5v CAN	✓	✓	✓	✓	-	-
Bendix	TABS6 Adv MC 5v CAN	✓	✓	✓	✓	-	-
Bendix	TPMS	✓	✓	-	-	-	-
Bendix	Tractor Lift Axle ABS	✓	✓	✓	✓	✓	Reset ABS Controller
Bendix	VORAD VS400/DIU	✓	✓	✓	-	-	-
Bendix	VS500	✓	✓	✓	-	-	-
Bendix	Wingman	✓	✓	✓	-	-	-