Diagnostic List Liebherr_v5.58

- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function 3.compared with the last version, the new added function is marked in red color.

	System	System	Function					
Engine type			Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Remark(other functions)
Perkins engine	BOSCH common rail EDC16UC40	Static diagnosis data	√	√	√	_	-	Read and write injector data
Perkins engine	BOSCH common rail EDC16UC40	Dynamic diagnosis data	√	-	_	√	√	_