

Diagnostic List Yanmar Machinery_v5.58

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Engine type	System	Function					Remark (other functions)
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	
Engine system	E13CTJ Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTK Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTM Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTL Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTN Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTP Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTR Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTS Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CTT Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	J08ETB Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	J08ETE Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	J08ETA Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J05DTA Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J05DTA Engine trial	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	P11CUH Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	P11CUJ Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CUN Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CUR Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CUK Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CUL Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	E13CUP Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>
Engine system	J07ETB Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and <u>vehicle speed limit setting function</u>

Diagnostic List Yanmar Machinery_v5.58

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Engine type	System	Function					Remark (other functions)
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	
Engine system	J05DTC Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVT Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUT Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETN Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETT Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETL Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETU Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUU Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUM Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUS Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUB Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUA Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUC Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUD Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUE Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05DTG Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05ETC Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05ETD Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETW Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUJ Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETV Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05DTF Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUY Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	P11CUR Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUR Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVA Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVB Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function

Diagnostic List Yanmar Machinery_v5.58

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Engine type	System	Function					Remark (other functions)
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	
Engine system	P11CUV Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUP Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUS Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUL Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUT Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EUU Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05ETF Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVC Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	Training Board	✓	✓	✓	✓	✓	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	A09C	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	A09CTJ	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	A09CTK	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J05ETB Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J05ETA Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	P11CUN Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J08ETM Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J05ETG Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	P11CUP Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	E13CUV Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J08ETH Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J08ETG Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J08EUK Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	P11CUT Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	N04CUA Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J08EUM Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J05ETH Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	J08EUN Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function
Engine system	P11CUU Engine	✓	✓	✓	✓	✓	Read and write injector data, boost test function