Diagnostic List Kia_v5.16

Remark:
1. √: means that the system has this function;
2. -: means that the system does not have this function;
3. compared with the last version, the new added function is marked in red color;

Vehicle Type	Year	Engine Type	System	SubSystem	Read ECU Info.	Read DTC	Erase DTC	Live Data	Actuation Test	Special Function
AM928,01~04	2004	D6AB(Q-ENG)	ENGINE	D6AB(Q-ENG)	√	√	√	√	√	√
AM928,01~04	2004	D6AB(Q-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
AM928,01~04	2003	D6AB(Q-ENG)	ENGINE	D6AB(Q-ENG)	√	√	√	√	√	√
AM928,01~04	2003	D6AB(Q-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
AM928,01~04	2002	D6AB(Q-ENG)	ENGINE	D6AB(Q-ENG)	√	√	√	√	√	√
AM928,01~04	2002	D6AB(Q-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
AM928,01~04	2001	D6AB(Q-ENG)	ENGINE	D6AB(Q-ENG)	√	√	√	√	√	√
AM928,01~04	2001	D6AB(Q-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
New Granbird,08~17	2017	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2017	D6CD(L-ENG)	SCR	Selective Catalytic Reduction	√	√	√	√	√	√
New Granbird,08~17	2017	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2017	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2017	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2017	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2017	D6CD(L-ENG)	EAPU	Electronic Air Processing Unit	√	√	√	√	-	√
New Granbird,08~17	2017	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2017	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2017	D6CD(L-ENG)	DTG/DIS	DTG(15EM)	√	√	√	√	√	√
New Granbird,08~17	2017	D6HA(H-ENG)	ENGINE	D6HA(H-ENG)	√	√	√	√	√	√
New Granbird,08~17	2017	D6HA(H-ENG)	SCR	Selective Catalytic Reduction	√	√	√	√	√	√
New Granbird,08~17	2017	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2017	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2017	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2017	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2017	D6HA(H-ENG)	EAPU	Electronic Air Processing Unit	√	√	√	√	-	√
New Granbird,08~17	2017	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2017	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2017	D6HA(H-ENG)	DTG/DIS	DTG(15EM)	√	√	√	√	√	√
New Granbird,08~17	2016	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2016	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2016	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2016	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2016	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2016	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2016	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2016	D6CD(L-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2016	D6CD(L-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2016	D6HA(H-ENG)	ENGINE	D6HA(H-ENG_10EM)	√	√	√	√	√	√
New Granbird,08~17	2016	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2016	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2016	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2016	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2016	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2016	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2016	D6HA(H-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2016	D6HA(H-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2015	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2015	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2015	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2015	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2015	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2015	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2015	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2015	D6CD(L-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2015	D6CD(L-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2015	D6HA(H-ENG)	ENGINE	D6HA(H-ENG_10EM)	√	√	√	√	√	√
New Granbird,08~17	2015	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2015	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2015	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2015	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2015	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2015	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2015	D6HA(H-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2015	D6HA(H-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2014	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2014	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2014	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2014	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2014	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2014	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2014	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2014	D6CD(L-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2014	D6CD(L-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2014	D6HA(H-ENG)	ENGINE	D6HA(H-ENG_10EM)	√	√	√	√	√	√
New Granbird,08~17	2014	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2014	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2014	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2014	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2014	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2014	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2014	D6HA(H-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2014	D6HA(H-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2013	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2013	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2013	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2013	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2013	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2013	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2013	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2013	D6CD(L-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2013	D6CD(L-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2013	D6HA(H-ENG)	ENGINE	D6HA(H-ENG_10EM)	√	√	√	√	√	√
New Granbird,08~17	2013	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2013	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2013	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2013	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2013	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2013	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2013	D6HA(H-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2013	D6HA(H-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2012	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2012	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2012	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√

New Granbird,08~17	2012	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2012	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2012	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2012	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2012	D6CD(L-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2012	D6CD(L-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2012	D6HA(H-ENG)	ENGINE	D6HA(H-ENG 10EM)	√	√	√	√	√	√
New Granbird,08~17	2012	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2012	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2012	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2012	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2012	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2012	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2012	D6HA(H-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2012	D6HA(H-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2011	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2011	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2011	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2011	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2011	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2011	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2011	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2011	D6CD(L-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2011	D6CD(L-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2011	D6CC(L-ENG)	ENGINE	D6CC(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2011	D6CC(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2011	D6CC(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2011	D6CC(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2011	D6CC(L-ENG)	DTG/DIS	DTG/DIS	√	-	-	√	-	√
New Granbird,08~17	2011	D6HA(H-ENG)	ENGINE	D6HA(H-ENG 10EM)	√	√	√	√	√	√
New Granbird,08~17	2011	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2011	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2011	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2011	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2011	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2011	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2011	D6HA(H-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2011	D6HA(H-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2010	D6HA(H-ENG)	ENGINE	D6HA(H-ENG)	√	√	√	√	√	√
New Granbird,08~17	2010	D6HA(H-ENG)	ENGINE	D6HA(H-ENG 10EM)	√	√	√	√	√	√
New Granbird,08~17	2010	D6HA(H-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2010	D6HA(H-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2010	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2010	D6HA(H-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2010	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2010	D6HA(H-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2010	D6HA(H-ENG)	DTG/DIS	DTG/DIS	√	-	-	√	-	√
New Granbird,08~17	2010	D6HA(H-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2010	D6HA(H-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2010	D6CC(L-ENG)	ENGINE	D6CC(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2010	D6CC(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2010	D6CC(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2010	D6CC(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2010	D6CC(L-ENG)	DTG/DIS	DTG/DIS	√	-	-	√	-	√
New Granbird,08~17	2010	D6CD(L-ENG)	ENGINE	D6CD(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2010	D6CD(L-ENG)	ABS	ABS(KNORR)	√	√	√	√	√	√
New Granbird,08~17	2010	D6CD(L-ENG)	EHS	Easy Hill Start	√	√	√	√	√	√
New Granbird,08~17	2010	D6CD(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2010	D6CD(L-ENG)	ECAS	ECAS(WABCO)	√	√	√	√	√	√
New Granbird,08~17	2010	D6CD(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2010	D6CD(L-ENG)	ECO	ECO-Drive	√	√	√	√	√	-
New Granbird,08~17	2010	D6CD(L-ENG)	DTG/DIS	DTG/DIS	√	√	√	√	-	√
New Granbird,08~17	2010	D6CD(L-ENG)	DTG/DIS	DTG(10EM)	√	√	√	√	-	√
New Granbird,08~17	2010	D6CD(L-ENG)	DTG/DIS	DIS	√	√	√	√	-	-
New Granbird,08~17	2009	D6CC(L-ENG)	ENGINE	D6CC(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2009	D6CC(L-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
New Granbird,08~17	2009	D6CC(L-ENG)	ECAS	Wabco ECAS	√	√	√	√	√	-
New Granbird,08~17	2009	D6CC(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2009	D6CC(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2009	D6CC(L-ENG)	DTG/DIS	DTG	√	-	-	√	-	√
New Granbird,08~17	2009	D6HA(H-ENG)	ENGINE	D6HA(H-ENG)	√	√	√	√	√	√
New Granbird,08~17	2009	D6HA(H-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
New Granbird,08~17	2009	D6HA(H-ENG)	ECAS	Wabco ECAS	√	√	√	√	√	-
New Granbird,08~17	2009	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2009	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2009	D6HA(H-ENG)	DTG/DIS	DTG	√	-	-	√	-	√
New Granbird,08~17	2008	D6CC(L-ENG)	ENGINE	D6CC(L-ENG)	√	√	√	√	√	√
New Granbird,08~17	2008	D6CC(L-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
New Granbird,08~17	2008	D6CC(L-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2008	D6CC(L-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2008	D6CC(L-ENG)	DTG/DIS	DTG	√	-	-	√	-	√
New Granbird,08~17	2008	D6HA(H-ENG)	ENGINE	D6HA(H-ENG)	√	√	√	√	√	√
New Granbird,08~17	2008	D6HA(H-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
New Granbird,08~17	2008	D6HA(H-ENG)	INTARDER	ZF Intarder	√	√	√	√	√	-
New Granbird,08~17	2008	D6HA(H-ENG)	BCM	BCM	√	√	√	√	√	√
New Granbird,08~17	2008	D6HA(H-ENG)	DTG/DIS	DTG	√	-	-	√	-	√
Granbird,01~07	2007	D6CB(L-ENG)	ENGINE	D6CB(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2007	D6CB(L-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
Granbird,01~07	2007	D6CB(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2006	D6CB(L-ENG)	ENGINE	D6CB(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2006	D6CB(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2006	D6CB(L-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
Granbird,01~07	2005	D6CB(L-ENG)	ENGINE	D6CB(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2005	D6CB(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2005	D6CB(L-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
Granbird,01~07	2004	D6CA(L-ENG)	ENGINE	D6CA(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2004	D6CA(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2004	D6CA(L-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
Granbird,01~07	2004	D6CB(L-ENG)	ENGINE	D6CB(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2004	D6CB(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2004	D6CB(L-ENG)	ABS	Knorr ABS6	√	√	√	√	√	√
Granbird,01~07	2003	D6CA(L-ENG)	ENGINE	D6CA(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2003	D6CA(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2003	D6AB(Q-ENG)	ENGINE	D6AB(Q-ENG)	√	√	√	√	√	√
Granbird,01~07	2003	D6AB(Q-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2002	D6CA(L-ENG)	ENGINE	D6CA(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2002	D6CA(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2002	D6AB(Q-ENG)	ENGINE	D6AB(Q-ENG)	√	√	√	√	√	√
Granbird,01~07	2002	D6AB(Q-ENG)	ABS	Bosch ABS	√	√	√	√	√	-
Granbird,01~07	2001	D6CA(L-ENG)	ENGINE	D6CA(L-ENG)	√	√	√	√	√	√
Granbird,01~07	2001	D6CA(L-ENG)	ABS	Bosch ABS	√	√	√	√	√	-

Granbird,01~07	2001	D6AB(Q-ENG)	ENGINE	D6AB(Q-ENG)	√	√	√	√	√	√
Granbird,01~07	2001	D6AB(Q-ENG)	ABS	Bosch ABS	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.7 IDI-J	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.7 IDI-J	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.7 IDI-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 3.0 IDI-J	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 3.0 IDI-J	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 3.0 IDI-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	L 2.4 THETA	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	L 2.4 THETA	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2018	L 2.4 THETA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	L 2.4 THETA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2018	L 2.4 THETA	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.7 IDI-J	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.7 IDI-J	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.7 IDI-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 3.0 IDI-J	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 3.0 IDI-J	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 3.0 IDI-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	L 2.4 THETA	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	L 2.4 THETA	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2017	L 2.4 THETA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	L 2.4 THETA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2017	L 2.4 THETA	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.7 IDI-J	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.7 IDI-J	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.7 IDI-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 3.0 IDI-J	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 3.0 IDI-J	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 3.0 IDI-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	L 2.4 THETA	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	L 2.4 THETA	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2016	L 2.4 THETA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	L 2.4 THETA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2016	L 2.4 THETA	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.9 C/R-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 3.0 IDI-J	Immobilizer	Immobilizer	–	√	√	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2015	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.9 C/R-J	Immobilizer	Immobilizer	–	–	–	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 3.0 IDI-J	Immobilizer	Immobilizer	–	√	√	√	–	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√

K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2014	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	-	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	-	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-A2	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2013	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	-	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	-	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-A2	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2012	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2011	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2010	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2009	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2008	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-

K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2007	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.9 C/R-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.9 C/R-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.9 C/R-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.9 C/R-J	Immobilizer	Immobilizer	-	-	-	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2006	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2005	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 2.7 IDI-J	Engine Control	Engine Control	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 2.7 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 2.7 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 3.0 IDI-J	Engine Control	Engine Control	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 3.0 IDI-J	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 3.0 IDI-J	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 3.0 IDI-J	Immobilizer	Immobilizer	-	√	√	√	-	√
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 2.5 TCI-4D56	Engine Control	Engine Control	-	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	-
K2500/K2700/K3000/K3000S(PU),04~18	2004	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√